




## Electric Table Lift

### Installation Manual

#### Package Contents:

- Electric Table Lift
- Wiring Harness and Control Switch
- Table Backer Board and Adhesive
- Mounting Hardware
  - (2) Control Switch Mounting Screws #6-3/4"
  - (6) #14-2.5" SPAX screws to attach table
  - (6) 2.5" SPAX Powerlags and washers to attach to floor
  - (3) Adhesive Backed Wire Clips



#### Notes:

The table backer board is used to gain more rigidity to the mounting area. It is designed to be used with an existing  $\frac{3}{4}$ " MDF table. The existing table itself does not have adequate depth for the mounting screws. **Caution: If your table is less than  $\frac{3}{4}$ " thick, the provided screws will be too long and protrude through the surface of the table! You will need to purchase your own appropriate length fasteners.** If your house currently has the 3 stage pedestal lift, you might have smaller backer already installed and it will need to be removed.

These instructions and dimensions are specific to Ice Castle Fish Houses with the full dinette in the rear. The wiring harness is sized to work with the dinette bench and wire to the battery located inside of the bench. Please contact us if you have any questions installing this unit in other applications.

#### **Caution:**

**Use care when extending or retracting the actuator during the assembly process. Keep hands and body parts away from moving parts.**